



Filling and care of your Powerbag

To fill the Powerbag use coarse grain sand that is dry, as wet sand may rot the liner. We recommend filling the bag outside to avoid any mess.

- 1.) Unzip the lid to the Powerbag and remove the foam end cap.
- 2.) Remove the (2) bags inside along with the (2) zip-ties.
- 3.) Take the plastic fill bag and place it on a scale. Next, fill the bag with the necessary amount of sand in order to get it to the correct weight and then tie off the bag with the (2) zip-ties. Make sure to get the ties as tight as possible and leave some room from the end of the bag.
- 4.) Once you have filled and tied the plastic bag you will then need to place this bag within the heavy nylon bag that was also inside the Powerbag. This bag has a draw strap on it already that you will need to tighten once the plastic sand filled bag is placed inside it.
- 5.) You will then need to place this entire unit into the Powerbag. This will take some adjusting of the sand filled bags as you will need to shift/shake the sides of the bags slightly in order to get the sand filled bags to slide into the Powerbag shell.
- 6.) Once the bags have been placed in the Powerbag shell, you will need to put the foam cap on top of the bags and zip the Powerbag shut.

We suggest that you periodically check the inner bags to check for any damage to them, or leaking of sand that may occur from using the bag.

- Store your Powerbag away from sunlight
- Although Powerbags are ideal for outdoor use, if they do become soaked for any reason dry them out and replace the sand.
- Wipe clean with a damp cloth periodically